


Magic Chef CAV2005AWW 04 - INNER - OUTER TUB



Magic Chef [Residential Magic Chef CAV2005AWW Washer Parts](#) Parts Diagram 04 - INNER - OUTER TUB
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7796	596669		Clamp, Manifold
2	21001749	21001748		Hose, Pressure Switch
3	22002960			Strainer, Washer Inlet
4	35-0874	76313		Hosefill
5	33-7891	89503		Hose-Inlet
6	21001531		Not Available	TOP, TUB (PLASTIC)
7	35-2328			Seal, Tub Top
8	21001529			Basket Assembly
9	21001875	285655		Clamp, Hose
10	21001872			Hose, Drain
11	22002765			Clip, Hose
12	25-6068	285655		Clamp, Hose
13	21001915			Hose, Tub To Pump
14	35-3700			Tub Assembly
15	21002006			Fabric Disp Assembly
16	21001521			Top, Agitator

17

[21001530](#)

Base, Agitator

18

25-8004

[W10309247](#)

Screw

19

25-7967

[3400504](#)

Screw

