


# Magic Chef CYE3004AZW 01 - CABINET



Magic Chef [Residential Magic Chef CYE3004AZW Dryer Parts](#) Parts Diagram 01 - CABINET  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">31001220</a>			Damper, Cabinet
"	<a href="#">31001527</a>			Reinfortment, Top
"	<a href="#">31001423</a>			Top, Cabinet
2	<a href="#">31001714</a>			Cabinet And Base Assembly
3	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">35-4128</a>			Pad, Hinge
"	<a href="#">63-5712</a>			Hinge, Cabinet Top
4	<a href="#">12002126</a>			Reinforcement Brace/Glide Kit
5	<a href="#">25-3034</a>			Clip, Wiring
6	<a href="#">33-2653</a>			Bumper, Cabinet
7	<a href="#">21001829</a>			Post, Locating
8	31001019		Not Available	CORD, POWER
9	53-0135		Not Available	SUPPORT, POWER CORD
"	25-7828	<a href="#">489483</a>		Screw 10-32 X 1/2
10	<a href="#">53-0284</a>			Cover, Terminal
				Screw, 8A X 3/8 HeX Washer

"	25-7857	<a href="#">90767</a>	Screw, 1/4 X 3/8 HEX WASHER Head Tapping
11	63-5519	Not Available	LEG, LEVELING
12	<a href="#">53-0120</a>		Clip, Front Panel
13	31001320	<a href="#">16515</a>	Clip
14	<a href="#">53-1921</a>		Shield, Wiring
"	25-7733	<a href="#">681414</a>	Screw, 10AB X 1/2
15	<a href="#">25-3457</a>		Screw, Sems
"	<a href="#">53-0133</a>		Shield, Heat
16	<a href="#">53-1625</a>		Brace, Tumbler Support
17	<a href="#">31001469</a>		Glide, Tumbler
18	<a href="#">31001356</a>		Pad, Glide
19	<a href="#">31001470</a>		Glide, Tumbler

**Howes**  
the laundry company®

**Howes**  
the laundry company®

**Howes**  
the laundry company®