


Magic Chef CYE3004AZW 05 - MOTOR & DRIVE



Magic Chef [Residential Magic Chef CYE3004AZW Dryer Parts](#) Parts Diagram 05 - MOTOR & DRIVE
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001572			Clip, Vent Pipe Ground
2	53-0134			Duct, Exhaust
3	31001589	W10410996		Motor-Drive
4	31001535			Pulley, Motor
5	53-1801			Housing, Blower
6	31001470			Glide, Tumbler
7	31001356			Pad, Glide
8	31001469			Glide, Tumbler
9	31001356			Pad, Glide
10	31001267	W10116760		Screw
11	25-7890	489478		Screw, 8 X 1/2
12	53-1026			Guide, Vane Inlet
13	31001088			Thermostat, Control
"	31001192			Thermostat, Control
14	25-7855			Ring, Retaining
15	25-7823	312967		Clamp, Blower Housing

16	31001541		Seal, Blower/Collector Duct
17	53-1625		Brace, Tumbler Support
18	53-1934		Cover, Blower Housing
19	31001317		Wheel, Blower
20	31001465		Spring, Idler
21	31001710		Idler Arm Assembly
22	53-0214	660658	Clamp, Motor Mounting 343481 685441
23	LA-1006		Glide Kit, Tumbler
24	31001570		Bracket, Motor

