


Magic Chef CYG1005AWW 03 - CONTROL PANEL & TOP



Magic Chef [Residential Magic Chef CYG1005AWW Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL & TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	37001233			Shield, Backguard
2	31001776			Control Panel
3	21001635	21001552		Frame , Control Panel
4	21001636	21001547		Endcap, Panel
5	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	56486		Not Available	BRACE, TOP
8	37001031	3370225		Screw
9	37001262			Timer - Dryer
10	37001283			Top As Pack
11	500121	510189		Pad Felt
12	21001629	21001546		Endcap, Panel