


Magic Chef CYG4000AWW 06 - MOTOR & DRIVE



Magic Chef [Residential Magic Chef CYG4000AWW Dryer Parts](#) Parts Diagram 06 - MOTOR & DRIVE
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001316	W10410996		Motor-Drve
"	53-0932	31001535		Pulley, Motor
2	25-7815			Washer
3	25-7732	681414		Screw, 10AB X 1/2
"	53-1932	31001570		Bracket, Motor
4	53-0214	660658		Clamp, Motor Mounting 343481 685441
5	53-2287			Idler Assembly
6	53-2209	31001465		Spring, Idler
7	25-2134	W10116760		Screw
"	53-0134			Duct, Exhaust
8	53-1801			Housing, Blower
9	53-0203	12001324		Duct Kit, Collector
10	31001317			Wheel, Blower
11	25-7823	312967		Clamp, Blower Housing
12	25-7855			Ring, Retaining
13	25-7435	33002917		Screw, No.10-16

"	53-1934		Cover, Blower Housing
14	31001192		Thermostat, Control
"	25-2134	W10116760	Screw
15	53-2273	31001470	Glide, Tumbler
16	53-0724	31001356	Pad, Glide
17	LA-1006		Glide Kit, Tumbler
18	53-2272	31001469	Glide, Tumbler
19	53-1684	31001356	Pad, Glide
20	25-7963	31001571	Screw, 10-24 x 0700 Hxwshrd Ty
21	25-7674		Screw
22	53-1026		Guide, Vane Inlet
23	25-3457		Screw, Sems
24	53-1625		Brace, Tumbler Support
25	25-7815		Washer
26	25-7957		Pushnut
27	53-1628	31001344	Pulley, Idler
28	53-2250	53-2287	Idler Assembly

