


Magic Chef W14EA1 04 - WATER CARRYING



Issued 3/86

E-3

Magic Chef [Residential Magic Chef W14EA1 Washer Parts](#) Parts Diagram 04 - WATER CARRYING
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	35-0059		Not Available	OVERFLOW HOSE
2	Y00000000		Not Available	SEE NOTE CLAMP (PURCHASE LOCALLY)
3	33-1389		Not Available	INSULATION
4	25-7796	596669		Clamp, Manifold
"	33-6714		Not Available	PRES SW HOSE
5	33-6099			Clamp
7	33-7314			Sump Assembly
8	33-3633		Not Available	HOSE
9	25-7003			Clamp
10	33-6091			Hose
11	Y00000000		Not Available	SEE NOTE CLAMP (PURCHASE LOCALLY)
12	Y00000000		Not Available	SEE NOTE CLAMP (PURCHASE LOCALLY)
13	35-0008	35-6467		Pump Assem
"	35-1069	35-6467		Pump Assem

14	33-6035		Not Available	PLATE & PULLEY ASSY.
15	33-6029	35-6467		Pump Assem
16	33-6360		Not Available	SEAL ASM
17	35-0010			Impeller
18	25-7418	33001178		Back, Tumbler
19	33-6032			Gasket
20	35-0009			Pump Housing
21	25-7405	3196164		Screw
22	25-7419		Not Available	SCREW
23	33-9535	211704		Hose, Drain
24	33-9536			Hose Adapter
25	25-7797	285655		Clamp, Hose
"	33-9537	22003814		Retainer, Drain Hose
26	33-6686		Not Available	FLUME
27	33-6038		Not Available	FLUME EXT
28	33-9979		Not Available	INLET HOSE
29	25-7867	596669		Clamp, Manifold
30	25-7866	489503		Clamp
31	33-7058		Not Available	SUB 36-1456
"	35-0085	35-2374N		Valve, Water
32	25-7101	3351614		Screw, Gearcase Cover Mounting
33	33-7891	89503		Hose-Inlet
34	33-7313	33-4264N		Strainer And Washer Kit
35	25-7048			Washer
36	33-3939		Not Available	SERVICE CORD

the laundry company[®]

the laundry company[®]