


# Magic Chef W18HA1 05 - EXTERIOR (REV. A-C)

SECTION: EXTERIOR  
MODEL: W18HN-1



Issue Date: 4/98

Magic Chef [Residential Magic Chef W18HA1 Washer Parts](#) Parts Diagram 05 - EXTERIOR (REV. A-C)  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	35-2341-24		Not Available	CLOTHES DOOR
"	35-2103-24		Not Available	CLOTHER DOOR
2	<a href="#">25-7436</a>			Nylite Washer
"	<a href="#">43-0057</a>			Actuator, Door Switch
3	<a href="#">25-7438</a>			Screw
4	<a href="#">33-6957</a>			Hinge Pad
"	25-7086	<a href="#">Y0308025</a>		Washer, Stainless Steel
5	25-7455	<a href="#">99002757</a>		Screw
6	<a href="#">33-6956</a>			Hinge
7	25-7455	<a href="#">99002757</a>		Screw
8	<a href="#">35-2064</a>			Bushing, Insulating
"	<a href="#">35-2063</a>			Bushing, Insulator
9	25-7463	<a href="#">7101P012-60</a>		Screw
10	25-7437	<a href="#">40040701</a>		Screw, Tapping No.6b-20
11	33-9064	<a href="#">12001187</a>		Kit, Lid Switch Assembly
"	33-8911	<a href="#">12001187</a>		Kit, Lid Switch Assembly

12	33-8289	<a href="#">12001187</a>		Kit, Lid Switch Assembly
"	25-7463	<a href="#">7101P012-60</a>		Screw
"	<a href="#">25-7436</a>			Nylite Washer
13	<a href="#">25-7878</a>			Clip
14	33-9063	<a href="#">12001187</a>		Kit, Lid Switch Assembly
15	35-2195-24		Not Available	CABINET TOP
"	35-2080-24		Not Available	CABINET TOP
16	25-7733	<a href="#">681414</a>		Screw, 10AB X 1/2
"	33-9906	<a href="#">21001167</a>		Dispenser, Bleach
17	35-0680		Not Available	CORD, POWER
18	<a href="#">25-7893</a>			Screw
19	33-7450	<a href="#">35-2846</a>		Hinge, Cabinet Top
20	<a href="#">33-0930</a>			Pad, Top Hinge
21	<a href="#">33-6099</a>			Clamp
22	<a href="#">53-0643</a>			Pin, Locator
23	<a href="#">34-9701</a>			Guide, Cabinet
24	25-0224	<a href="#">3400029</a>		Nut, Adapter Plate
25	<a href="#">53-0643</a>			Pin, Locator
26	25-7732	<a href="#">681414</a>		Screw, 10AB X 1/2
"	<a href="#">35-2084</a>			Panel, Front
"	35-2084-25		Not Available	PANEL, FRONT
"	<a href="#">35-2084-24</a>			Panel, Front
27	<a href="#">53-0120</a>			Clip, Front Panel
28	<a href="#">33-2653</a>			Bumper, Cabinet
29	35-2106-25		Not Available	CABINET ASSY. (HW)
"	35-2106-24	<a href="#">12001802</a>		Kit, Cabinet/Rear Shield
"	35-2106	<a href="#">21001871</a>		Cabinet
30	<a href="#">33-2653</a>			Bumper, Cabinet
31	35-2108	<a href="#">21001871</a>		Cabinet
32	25-7086	<a href="#">Y0308025</a>		Washer, Stainless Steel
33	33-8057		Not Available	PLASTIC NUT
34	33-8058		Not Available	SPEEDNUT
35	<a href="#">25-6109</a>			Screw
36	<a href="#">34-9701</a>			Guide, Cabinet
37	<a href="#">25-7285</a>			Clip

