


Magic Chef W205KGA 01 - BASE



Magic Chef [Residential Magic Chef W205KGA Washer Parts](#) Parts Diagram 01 - BASE
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	21001110	22004376		Spring, Motor Pivot
2	21001231	LA-2003		Motor Replacement Kit
"	LA-2003			Motor Replacement Kit
3	21001109	21001486		Foot Slide, Isolator
"	33-9945			Slide, Foot
4	25-7418	33001178		Back, Tumbler
5	25-7833	21001977		Screw
6	25-7834			Washer, Motor/Base Screw
7	33-9946			Isolator, Motor
8	33-9944	35-3570		Washer, Motor Pivot
9	35-2810	21001783		Plate And Screw Assembly
"	21001111	21001783		Plate And Screw Assembly
10	33-9941	35-3646		Isolator, Motor Plate
"	35-3646			Isolator, Motor Plate
11	25-7831			Spacer, Mounting
12	21001108			Pulley, Motor

"	33-1171	21001833		Pulley, Motor
13	25-7117			Set Screw
14	33-9943	35-3571		Slide, Motor Pivot
15	33-9967			Washer, Motor Isolator
16	25-7047			Washer, Flat
17	25-7325	Y707702		Locknut
18	35-3658			Spring, Suspension
"	21001138	22002922		Tool, Spring Removal
"	21001165			Spring, Suspension
19	21001166			Hook, Suspension Spring
"	35-2976		Not Available	HOOK, SUSPENSION SPRING
20	35-2049	21001881		Bar, Stabilizer
21	35-2046			Bracket, Stabilizer
22	35-2052			Pin, Stabilizer
23	35-2050	22004469		Leg And Foot Self Stabalizing
24	35-3020	22004469		Leg And Foot Self Stabalizing
"	21001169	12002701		Base Kit
25	35-2984		Not Available	BASE
26	25-7838	25-7845		Speednut, Motor
27	25-7915			Hex Nut
28	35-0837	25001119		Foot And Pad Assembly
"	35-0772	25001119		Foot And Pad Assembly
29	Y25-7951			Washer, Suspension Hook
30	35-2279			Belt, Drive
31	25-7830			Spacer
32	33-9765			Switch, Motor
33	21001161	21002026		Snubber
"	35-2065			Pad, Motor Plate
34	35-3788	21002026		Snubber

