


# Magic Chef W20EA4 01 - BASE & DRIVE



Magic Chef [Residential Magic Chef W20EA4 Washer Parts](#) Parts Diagram 01 - BASE & DRIVE  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">35-0058</a>			Base Assembly
2	<a href="#">25-7365</a>			Eye Bolt
3	33-9553		Not Available	SPRING
4	<a href="#">25-7362</a>			Anchor Nut
5	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE (PURCHASE LOCALLY)
6	34-0061	<a href="#">35-0771</a>		Leveling Leg
"	33-0679	<a href="#">35-0771</a>		Leveling Leg
7	25-7032	<a href="#">25-7915</a>		Hex Nut
8	34-0062	<a href="#">25001119</a>		Foot And Pad Assembly
9	35-0465		Not Available	DRIVE BELT
10	33-9374		Not Available	DRIVE PULLEY
11	25-7361		Not Available	SET SCREW
12	33-9952		Not Available	MOTOR PULLEY
13	<a href="#">25-7117</a>			Set Screw
14	<a href="#">LA-1010</a>			Motor Kit

15	35-0259	Not Available	MOTOR SWITCH
"	<a href="#">33-9765</a>		Switch, Motor
16	<a href="#">33-9945</a>		Slide, Foot
17	25-7779	Not Available	SCREW
18	<a href="#">25-7830</a>		Spacer
19	<a href="#">33-9946</a>		Isolator, Motor
20	33-9944	<a href="#">35-3570</a>	Washer, Motor Pivot
21	<a href="#">33-9942</a>		Motor Plate
22	33-9947	Not Available	DBL.PIVOT SLIDE
23	25-3083	<a href="#">212951</a>	Screw, No.6-32 X 1/4 Inch
24	33-9941	<a href="#">35-3646</a>	Isolator, Motor Plate
25	<a href="#">25-7831</a>		Spacer, Mounting
26	33-9943	<a href="#">35-3571</a>	Slide, Motor Pivot
27	<a href="#">33-9967</a>		Washer, Motor Isolator
28	<a href="#">25-7047</a>		Washer, Flat
29	25-0224	<a href="#">3400029</a>	Nut, Adapter Plate
30	<a href="#">25-7834</a>		Washer, Motor/Base Screw
31	25-7833	<a href="#">21001977</a>	Screw
32	25-7265	Not Available	WIRING CLAMP
33	25-7218	Not Available	SCREW
34	<a href="#">35-0235</a>		Spring, Motor Pivot
35	<a href="#">33-9579</a>		Susp Housing
36	63-5225	<a href="#">21001840</a>	Bearing
37	25-7360	<a href="#">25-7850</a>	Retaining Ring
38	<a href="#">33-9569</a>		Tub Brace
39	33-9391	Not Available	BRACKET
40	<a href="#">25-7359</a>		Screw
"	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE (PURCHASE LOCALLY)
41	<a href="#">33-6880</a>		Bracket
42	25-7275	Not Available	SCREW
43	25-7413	Not Available	FLAT WASHER
44	25-7089	Not Available	LOCKWASHER
45	33-4287N	Not Available	BRAKE LATCH KIT
"	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE (PURCHASE LOCALLY)
46	33-9576	Not Available	BRAKE LATCH
47	<a href="#">33-9966</a>		Brk Ltch Bearng
48	33-0279	Not Available	WASHER
49	25-7843	Not Available	BOLT
50	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE (PURCHASE LOCALLY)
51	25-7844	<a href="#">25-7304</a>	Locknut
52	33-8291	Not Available	BRAKE SOLENOID
53	25-7432	Not Available	SCREW
54	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE (PURCHASE LOCALLY)
55	33-9521	Not Available	BRAKE LINK
56	33-7519	Not Available	BRAKE SPRING
57	33-9554	Not Available	SUPPORT BRACE
58	25-7549	Not Available	FLAT WASHER
59	25-7275	Not Available	SCREW

60	25-7413	Not Available	FLAT WASHER
61	25-7089	Not Available	LOCKWASHER
62	25-7798	Not Available	HEX NUT
63	25-7838	<a href="#">25-7845</a>	Speednut, Motor

