


Magic Chef W20EA4 05 - WATER CARRYING

MAGIC CHEF W20EN-4 WATER CARRYING



Issued 4/86

B-10

Magic Chef [Residential Magic Chef W20EA4 Washer Parts](#) Parts Diagram 05 - WATER CARRYING
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	35-0059		Not Available	OVERFLOW HOSE
2	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE (PURCHASE LOCALLY)
3	33-1389		Not Available	INSULATION
4	25-7796	596669		Clamp, Manifold
"	33-4090		Not Available	HOSE
5	33-6099			Clamp
6	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE (PURCHASE LOCALLY)
7	33-7314			Sump Assembly
8	33-3633		Not Available	HOSE
9	25-7003			Clamp
10	33-6091			Hose
11	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE (PURCHASE LOCALLY)
				NOT REQUIRED PART OR

12	W10124350		Not Available	SEE NOTE (PURCHASE LOCALLY)
13	35-0008	35-6467		Pump Assem
14	33-6035		Not Available	PLATE & PULLEY ASSY.
15	33-6029	35-6467		Pump Assem
16	33-6360		Not Available	SEAL ASM
17	35-0010			Impeller
18	25-7418	33001178		Back, Tumbler
19	33-6032			Gasket
20	35-0009			Pump Housing
21	25-7405	3196164		Screw
22	25-7419		Not Available	SCREW
23	33-9535	211704		Hose, Drain
24	33-9536			Hose Adapter
25	25-7797	285655		Clamp, Hose
"	33-9537	22003814		Retainer, Drain Hose
26	33-8057		Not Available	PLASTIC NUT
"	25-7086	Y0308025		Washer, Stainless Steel
"	33-9830		Not Available	INLET FLUME
"	25-7455	99002757		Screw
27	33-6038		Not Available	FLUME EXT
28	35-0541		Not Available	WATR INLET HOSE
29	25-7867	596669		Clamp, Manifold
30	25-7866	489503		Clamp
31	33-7058		Not Available	SUB 36-1456
"	35-0085	35-2374N		Valve, Water
32	25-7101	3351614		Screw, Gearcase Cover Mounting
33	33-7891	89503		Hose-Inlet
34	33-7313	33-4264N		Strainer And Washer Kit
35	25-7048			Washer
36	33-3939		Not Available	SERVICE CORD

