


Magic Chef W20JN4S 09 - TUB

SECTION: TUB
MODEL: W20JN-4S



Issue Date: 4/91

Magic Chef [Residential Magic Chef W20JN4S Washer Parts](#) Parts Diagram 09 - TUB

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|--------------------------|---------------|------------------------|
| 1 | 35-2456 | 33-4352 | | Agitator |
| 2 | 35-2062 | 21001063 | | Screw, Shoulder |
| 3 | 25-7914 | 22002933 | | Screw |
| 4 | 33-6241 | | | Cap |
| 5 | 33-8959 | | | Gasket |
| 6 | 35-2061 | | | Gasket, Tub To Housing |
| 7 | 33-8799 | | Not Available | REINF PLATE |
| 8 | 25-7783 | 4356852 | | Screw |
| 9 | 35-2328 | | | Seal, Tub Top |
| 10 | 25-7330 | | | Rubber Washer |
| 11 | 35-2508 | | Not Available | BASKET WHITE |
| 12 | 35-2023 | | | Tub Support |
| 13 | 35-2038 | | | Tub |
| 14 | 35-2034 | | Not Available | TOP, TUB |
| " | 35-2262 | | Not Available | SHIELD, TUB TOP |
| 15 | 33-9827 | 35-2550 | | Dispenser, Rinse |