


Magic Chef W20JY4SC 09 - TUB (W20JN4SC)(REV. A)



Magic Chef [Residential Magic Chef W20JY4SC Washer Parts](#) Parts Diagram 09 - TUB (W20JN4SC)(REV. A)

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|---------------|-----------------------------|
| 1 | 35-2717 | 35-3580 | | Agitator |
| 2 | 25-7949 | | Not Available | RING, RETAINING (AG. SHAFT) |
| 3 | 25-7953 | 22002933 | | Screw |
| 4 | 25-7948 | W10309247 | | Screw |
| 5 | 33-8959 | | | Gasket |
| 6 | 35-2979 | | | Gasket, Tub/Hsg |
| 7 | 33-8799 | | Not Available | REINF PLATE |
| 8 | 25-7783 | 4356852 | | Screw |
| 9 | 35-2328 | | | Seal, Tub Top |
| 10 | 35-2733 | | | Cap, Agitator |
| 11 | 35-3016 | | Not Available | BASKET ASSY |
| 12 | 35-2978 | | | Seal, Tub/Housing |
| 13 | 35-2952 | 35-3700 | | Tub Assembly |
| 14 | 35-2262 | | Not Available | SHIELD, TUB TOP |
| " | 35-2034 | | Not Available | TOP, TUB |
| 15 | 35-2550 | | | Dispenser, Rinse |

