


WATER CARRYING



W25EN2

C-12

Magic Chef [Residential Magic Chef W25EY2 Washer Parts](#) Parts Diagram 05 - WATER CARRYING
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	35-0059		Not Available	OVERFLOW HOSE
3	33-1389		Not Available	INSULATION
4	25-7796	596669		Clamp, Manifold
"	33-6096		Not Available	HOSE 48"
5	33-6099			Clamp
7	33-7314			Sump Assembly
8	33-6091			Hose
9	25-7003			Clamp
10	33-6091			Hose
13	35-0008	35-6467		Pump Assem
14	33-6035		Not Available	PLATE & PULLEY ASSY.
15	33-6029	35-6467		Pump Assem
16	33-6360		Not Available	SEAL ASM
17	35-0010			Impeller
18	25-7418	33001178		Back, Tumbler
19	33-6032			Gasket

20	35-0009		Pump Housing
21	25-7405	3196164	Screw
22	25-7419		Not Available SCREW
23	33-9535	211704	Hose, Drain
24	33-9536		Hose Adapter
25	25-7797	285655	Clamp, Hose
"	33-9537	22003814	Retainer, Drain Hose
26	33-9830		Not Available INLET FLUME
"	25-7086	Y0308025	Washer, Stainless Steel
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	33-8057		Not Available PLASTIC NUT
27	33-6038		Not Available FLUME EXT
28	35-0541		Not Available WATR INLET HOSE
29	25-7867	596669	Clamp, Manifold
30	25-7866	489503	Clamp
31	33-7058		Not Available SUB 36-1456
"	35-0086	39-1482	Mixing Valve
32	25-7101	3351614	Screw, Gearcase Cover Mounting
33	33-7891	89503	Hose-Inlet
34	33-7313	33-4264N	Strainer And Washer Kit
35	25-7048		Washer
36	33-3939		Not Available SERVICE CORD

