


Magic Chef YE208KV 01 - CABINET (YE208KV)



Magic Chef [Residential Magic Chef YE208KV Dryer Parts](#) Parts Diagram 01 - CABINET (YE208KV)
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|--------------------------|---------------|---|
| 1 | 53-2435 | | Not Available | TOP, CABINET |
| 2 | 53-2559 | 31001714 | | Cabinet And Base Assembly |
| " | 53-2147 | 31001714 | | Cabinet And Base Assembly |
| 3 | 63-5712 | | | Hinge, Cabinet Top |
| 4 | 25-3092 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| " | 33-0930 | | | Pad, Top Hinge |
| 5 | 25-3034 | | | Clip, Wiring |
| 6 | 33-2653 | | | Bumper, Cabinet |
| 7 | 53-0643 | | | Pin, Locator |
| 8 | 53-0200 | | | Sleeve, Locator Pin |
| " | 25-0224 | 3400029 | | Nut, Adapter Plate |
| 9 | 53-0135 | | Not Available | SUPPORT, POWER CORD |
| " | 25-7828 | 489483 | | Screw 10-32 X 1/2 |
| 10 | 53-0284 | | | Cover, Terminal |
| " | 25-7857 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |

11

[25-3457](#)

Screw, Sems

"

[53-0133](#)

Shield, Heat

"

[53-2350](#)

Shield, Heat

"

[53-0133](#)

Shield, Heat

