


Magic Chef YE20JA5C 04 - HEATER (YE20JA5C)(REV. A)



Magic Chef [Residential Magic Chef YE20JA5C Dryer Parts](#) Parts Diagram 04 - HEATER (YE20JA5C)(REV. A)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7863			Screw
"	53-0920	LA-1044		Element
2	25-7819	M0217225		Screw
"	53-1232			Heater Housing Assembly
3	53-1493			Thermostat
"	25-3083	212951		Screw, No.6-32 X 1/4 Inch
4	53-0285			Bracket, Thermostat
"	25-7741	W10116760		Screw
5	35-2257	7401P037-60		Block, Terminal
"	25-0027	112432		Nut
"	25-6124		Not Available	NUT
"	25-3123		Not Available	WASHER, CUP
"	25-3122			Washer, Flat
"	25-7803	3400074		Screw
6	LA-1053			Fuse Kit, Thermal
7	53-1181			Bracket, Thermal Fuse