


Magic Chef YE225LVC 02 - CONTROL PANEL (YE225LVC)



Magic Chef [Residential Magic Chef YE225LVC Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL (YE225LVC)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001136			Panel, Control
2	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2669		Not Available	CAP, END (LT)(WHT)
"	35-2668	21001453		Cap- End
3	25-7702			Speedclip, End Cap To Control Panel
4	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-1639			Buzzer Assembly
5	31001054		Not Available	TRIM, ENDCAP (RT WHT)
"	31001055		Not Available	TRIM, ENDCAP (LT WHT)
6	25-7760			Screw
7	25-7851			Speedclip, End Cap To Top
8	25-7649	910187		Screw
9	31001128		Not Available	SHIELD, CONTROL
"	31001146	31001193		Pad, Shield

10	35-2688	21001460	Shield, Rear
11	63-6743	31001484	Resistor Assembly
"	53-1758		Timer
12	31001119	W10116760	Screw
13	53-2502		Knob And Skirt Assembly
14	31001150	Not Available	SWITCH, HEAT
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
15	35-3961	21001239	Knob, Selector
16	16000329	Not Available	GUIDE, QUICK REF. - MAGIC CHEF
"	31001050	Not Available	MANUAL, USE & CARE
"	31001189	Not Available	MANUAL, USE & CARE

Howes
the laundry company®

Howes
the laundry company®

Howes
the laundry company®