


Maytag 3UMTW5755TW1 01 - TOP AND CABINET PARTS



Maytag [Residential Maytag 3UMTW5755TW1 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10131567		Not Available	Use & Care Guide (English)
"	W10117891		Not Available	Use & Care Guide (Arabic)
"	W10131593		Not Available	Feature Sheet (English)
"	W10117897		Not Available	Feature Sheet (Arabic)
"	W10121779		Not Available	Wiring Diagram
2	W10093782	W10193868		Lid
3	9724509			Bumper, Lid
4	W10119828			Screw, Lid Hinge Mounting
5	W10225136			Hinge 7 Pad Assembly
6	91770			Hinge, Lid
7	62780			Clip, Top And Cabinet And Rear Panel
8	W10192089			Dispenser, Bleach
9	3351614			Screw, Gearcase Cover Mounting
10	8318084			Switch, Lid
11	8319539			Bearing, Lid Hinge

12	W10194868	Top
13	62750	Spacer, Cabinet To Top (4)
14	63424	Cabinet
15	3390631	Screw, 10-16 X 3/8
16	W10177046	Cabinet - Damper, Sound

