


Maytag 4GMVWC400YW0 02 - CONSOLE AND WATER INLET PARTS



Maytag Residential Maytag 4GMVWC400YW0 Washer Parts Parts Diagram 02 - CONSOLE AND WATER INLET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10365086			Panel, Console
2	8536939			Clip, Knob
3	W10193824			Endcap Console Bracket
4	W10193821			Cap, End
5	8312709			Clip-Console
6	W10480701			Control Unit Assembly, Machine And Motor
7	W10420985			Panel, Console Rear Cover
8	1157158	489069		Xxscrew, 10-12 X 1/2
9	W10285512			Switch, Rotary Encoder
10	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
11	W10422755			Cord, Power
NI	N/P		Not Available	PARTS NOT SHOWN
"	W10446855			10A Cord Lock
"	W10476822			10A Cord Adapters:

"	W10476820		10A Cord Adapters:
"	W10475423		10A Cord Adapters: Type B
12	3400076		Screw, Bracket Mounting
13	W10317454		Timer Knob And Dial Assembly
14	W10317455		Knob, Push-To-Start
15	W10285511		Switch, Rotary Encoder
16	W10291177		Harness, Upper
17	W10345523		Inlet Assembly, Water
18	W10339585	Not Available	VALVE, WATER MIXING
19	W10441423		Vacuum Break
20	W10238347		Hose, Vacuum Break
21	W10117298	596669	Clamp, Manifold
22	W10344775		Harness, Valve
23	8281163		Screw, Dispenser Housing Mounting
24	W10323734		Badge, Assembly
25	688805		Clip, Spring Knob
26	359625	487240	Screw, For Mtg. Service Capacitor
27	3400073		Screw, Ground
28	W10251309		Pushbutton, Start

