


# Maytag 4KMTW5755TW0 03 - AGITATOR, BASKET AND TUB PARTS

## AGITATOR, BASKET AND TUB PARTS

For Model: 4KMTW5755TW0  
(White/Grey)



W10128845

5

Maytag [Residential Maytag 4KMTW5755TW0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8565968</a>			Dispenser, Fabric Softener
2	3354733	<a href="#">W10074580</a>		Cap, Barrier
3	3348855	<a href="#">W10072840</a>		Fabric Softener
4	<a href="#">358237</a>			Screw And Washer
5	<a href="#">3949550</a>			Washer
6	<a href="#">W10093672</a>			Agitator
7	3363663	<a href="#">285811</a>		Cam-Agitator
8	3366877	<a href="#">80040</a>		Dog-Agitator
9	<a href="#">3363661</a>			Bearing, Driven Cam
10	<a href="#">3349019</a>			Auger, Agitator
11	3350389	<a href="#">285587</a>		Washer
12	<a href="#">W10110020</a>			Agitator
13	8528150	<a href="#">W10445870</a>		Ring-Tub
14	<a href="#">3976308</a>			Gasket, Tub Ring
15	<a href="#">3354845</a>			Clip, Agitator
16	<a href="#">8543666</a>			Washer, Agitator

17	8519788	<a href="#">387240</a>	Ring, Balance
18	<a href="#">21366</a>		Nut, Spanner
19	8526016	<a href="#">W10389328</a>	Clothes Container, Assembly
20	<a href="#">2219077</a>		Clip, Pressure Switch Hose
21	3347780	<a href="#">353244</a>	Hose, Pressure Switch
22	<a href="#">389140</a>		Tub Block, Basket Drive
23	<a href="#">63849</a>		Strain Relief, Power Cord
24	<a href="#">383727</a>		Gasket, Centerpodt

