


Maytag 4KMTW5955TW0 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Model: 4KMTW5955TW0
(White/Grey)



W10128844

5

Maytag [Residential Maytag 4KMTW5955TW0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8528278			Dispenser, Fabric Softener
2	358237			Screw And Washer
3	3949550			Washer
4	8538246			Agitator
5	8537433			Cam, Driven
6	8533540			Retainer, Spring
7	3946997			Spring, Compression
8	3366877	80040		Dog-Agitator
9	8055141			Bearing-Driven Cam
10	3946996			Auger, Agitator
11	3947517			Agitator
12	3954507	W10213410		Ring-Tub
13	3359585	3976308		Gasket, Tub Ring
14	8318246	W10213410		Ring-Tub
15	3354845			Clip, Agitator
16	8543666			Washer, Agitator

17	W10116602		Nut, Spanner
18	W10118233	W10006326	Balance Ring
19	8579546		Basket And Balance Ring
20	2219077		Clip, Pressure Switch Hose
21	3347780	353244	Hose, Pressure Switch
22	389140		Tub Block, Basket Drive
23	8283125		Tub
24	3948705		Hose, Bleach
25	383727		Gasket, Centerpodt

