


Maytag 4KMTW5955TW1 01 - TOP AND CABINET PARTS



Maytag Residential Maytag 4KMTW5955TW1 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10117890		Not Available	Use & Care Guide (English)
"	W10117891		Not Available	Use & Care Guide (Arabic)
"	W10117896		Not Available	Feature Sheet (English)
"	W10117897		Not Available	Feature Sheet (Arabic)
"	W10117059		Not Available	Wiring Diagram
2	8054939			Seal, Lid
3	21097			Pad, Lid Hinge
4	W10171569	W10193865		Lid
5	W10119828			Screw, Lid Hinge Mounting
6	8319539			Bearing, Lid Hinge
7	3351614			Screw, Gearcase Cover Mounting
8	8318084			Switch, Lid
9	W10225136			Hinge 7 Pad Assembly
10	54583			Hinge, Lid
11	19119			Bumper, Lid Hinge
				Clip, Top And Cabinet And

12	62780		Clip, Top And Cabinet And Rear Panel
13	W10192089		Dispenser, Bleach
14	W10194866		Top
15	62750		Spacer, Cabinet To Top (4)
16	3950968	63424	Cabinet
17	3390631		Screw, 10-16 X 3/8
18	W10177046		Cabinet - Damper, Sound

