


# Maytag 4KMVWC405WQ0 03 - AGITATOR, BASKET AND TUB PARTS



Maytag [Residential Maytag 4KMVWC405WQ0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3347674	<a href="#">285727</a>		Agitator
2	<a href="#">358237</a>			Screw And Washer
3	389141	<a href="#">3360824</a>		Auger, Agitator
4	3350389	<a href="#">285587</a>		Washer
5	<a href="#">389386</a>			Agitator
6	8528150	<a href="#">W10445870</a>		Ring-Tub
7	<a href="#">3976308</a>			Gasket, Tub Ring
8	<a href="#">21366</a>			Nut, Spanner
9	8526017	<a href="#">W10389329</a>		Clothes Container, Assembly
10	63973	<a href="#">3362061</a>		Cap
11	W10135425	<a href="#">63849</a>		Strain Relief, Power Cord
12	<a href="#">358912</a>			Seal, Agitator Cap
13	<a href="#">389140</a>			Tub Block, Basket Drive
14	<a href="#">383727</a>			Gasket, Centerpodt
15	3347780	<a href="#">353244</a>		Hose, Pressure Switch
16	<a href="#">3949550</a>			Washer

17	3363662	<a href="#">285748</a>	Cam-Agitator
18	3366877	<a href="#">80040</a>	Dog-Agitator
19	<a href="#">3363661</a>		Bearing, Driven Cam
20	<a href="#">387240</a>		Ring, Balance
21	<a href="#">2219077</a>		Clip, Pressure Switch Hose

