



[Maytag Residential Maytag 601C Dryer Parts](#) Parts Diagram 04 - HEATING ELEMENT, WIRING & CONTROLS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y300059		Not Available	MICRO SWITCH---NA
2	300243		Not Available	WIREING HARNESS FOR MTR/THERM.
3	300244		Not Available	WIRING HARNESS-TIMER & DOOR SW
4	300245		Not Available	No.20 WIRE W/TERMINALS
5	300252		Not Available	SOCKET FOR PILOT LAMP
6	300254		Not Available	THERMOSTAT
7	300256		Not Available	HIGH LIMIT THERMOSTAT
8	300262		Not Available	TIMER
9	300263			No.26 Wire W/Terminals
10	Y300266	400008		Block, Terminal
11	300290		Not Available	TIMER
12	300291		Not Available	THERMOSTAT
13	300292		Not Available	LAMP SOCKET
14	300304	303650		Valve-Inlet
15	300318		Not Available	No.3 WIRE W/TERMINALS

16	300425		Not Available	WIRE HARNESS FOR DOOR SWITCH
17	300429		Not Available	MAIN WIRE HARNESS
18	300635		Not Available	No.2 WIRE
19	301945		Not Available	No.15 WIRE W/TERMINAL
20	Y302000			Heater Coil With Frame
21	310154		Not Available	TERMINAL FOR MOTOR
22	310207			Screw, No.6 X 1/4 Inch
23	310289		Not Available	TERMINAL FOR DRUM LIGHT WIRE
24	310547		Not Available	TERMINAL FOR WIRES
25	Y311916	22003781		Screw, Ground Strap
26	200046		Not Available	CONNECTOR, FEMALE
27	200272		Not Available	CONNECTOR, 3 WIRE
28	210175		Not Available	WIRE CONNECTOR
29	Y052684	112432		Nut
30	Y052721			Nut, Terminal Block Plate

