



[Maytag Residential Maytag 640C Dryer Parts Parts Diagram 01 - CABINET REMOVED](#)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	300017		Not Available	BEARING ASSEMBLY
2	300056		Not Available	SOCKET FOR DRUM LAMP
3	300107			Drum Pulley
4	300122		Not Available	SLIDE SHAFT
5	300181		Not Available	BASE BRAME ASSY
6	300238		Not Available	ELBOW
7	300245		Not Available	No.20 WIRE W/TERMINALS
8	300249	675659		Gasket
9	300256		Not Available	HIGH LIMIT THERMOSTAT
10	300261		Not Available	HEATER CHAMBER ASSY
11	300263			No.26 Wire W/Terminals
12	Y300266	400008		Block, Terminal
13	300290		Not Available	TIMER
14	300304	303650		Valve-Inlet
15	300318		Not Available	No.3 WIRE W/TERMINALS
16	300319		Not Available	No.4 WIRE

17	300381		Gasket
18	300416	Not Available	DRUM ASSEMBLY
19	300425	Not Available	WIRE HARNESS FOR DOOR SWITCH
20	300429	Not Available	MAIN WIRE HARNESS
21	300435	Not Available	PULLEY
22	300436		Pulley
23	300445	675274	Washer
24	300537	Not Available	No.27 WIRE
25	300546	Not Available	No.28 WIRE WITH TERMINALS
26	300551		Thermostat
27	300552	Not Available	LAMP SOCKET
28	300561	Not Available	CASING ASSY
29	300635	Not Available	No.2 WIRE
30	300824		Reduction Pulley
31	300935	Not Available	FELT SEAL
32	Y301388	Not Available	POWER CORD
33	301945	Not Available	No.15 WIRE W/TERMINAL
34	Y302000		Heater Coil With Frame
35	Y302278		Motor
36	310176	Not Available	WASHER BEHIND DRUM PULLEY
37	Y310190	Not Available	V BELT-COG
38	310204	Not Available	SNAP RING
39	310207		Screw, No.6 X 1/4 Inch
40	310226	Not Available	WASHER
41	310231	Not Available	SEAL FOR DRUM SHAFT
42	310254	Not Available	MOTOR BASE
43	310259	Not Available	GUIDE ROD
44	310260	Not Available	SPRING
45	310261	Not Available	GROMMET
46	310262		Washer
47	310292	Not Available	SCREW-TERMINAL BLOCK TO BRKT
48	310308	Not Available	SCREW, IN CASING ASSY
49	310361	Not Available	COG BELT-LOWER
50	Y310376		Clip, Door Switch Harness
51	310401	Not Available	INSULATION FOR TOP (15"X18")
52	310402	Not Available	INSULATION FOR CABINET
53	300487	Not Available	HEATER CHAMBER ASSY
54	310403	Not Available	INSULATION FOR HEATER PANEL
55	310405	Not Available	FAN HOUSING
56	310411	Not Available	GROMMET
57	310413	312535	Washer, Vault Mounting Brk.
58	310415	Not Available	BELT
59	310429	Not Available	END CAP
60	310543	Not Available	OZONE LAMP-4 WATT
61	310544	Not Available	SOCKET FOR OZONE LAMP
62	310551		Fastener
63	310565	Not Available	GASEKT FOR COMBUSTION HOOD
64	310566	Not Available	PLUG BUTTON

65	310578		Not Available	WASHER
66	310579		Not Available	SCREW, No.10-24 X 11/16 INCH
67	310583		Not Available	WASHER
68	310587		Not Available	LAMP
69	310598		Not Available	WASHER 5/32 X 3/8 INCH
70	310628		Not Available	WASHER
71	310644	314210		Swtch-Prct
72	310645		Not Available	SHAFT
73	310754		Not Available	WASHER (STAINLESS STEEL)
74	310768		Not Available	WASHER
75	310830		Not Available	BLOWER IMPELLER
76	Y310842	8182296		Screw, Agitator
77	310843		Not Available	SCREW-HEATER CHAMBER TO CASING
78	310934	22003428		Leg, Adjustable
79	Y311916	22003781		Screw, Ground Strap
80	312206		Not Available	TERMINAL BRACKET
81	200046		Not Available	CONNECTOR, FEMALE
82	200272		Not Available	CONNECTOR, 3 WIRE
83	200424			Motor Bracket
84	210175		Not Available	WIRE CONNECTOR
85	210310	31001575		Bulb, Cylinder Light
86	210385			Lock Nut For Adjustable Leg
87	210684			Foot, Adjustable Leg
88	210887	12990527		Screw-Sm/Hex
89	211737	248562		Terminal
90	Y014872			Screw, Coin Meter Stop -
91	014873	911772		Screw
92	015700		Not Available	CAP SCREW, 1/4-20 X 1/2
93	Y052659	Y052655		Hex Nut, No.8-32
94	Y052679	M0282009		Nut
95	Y052684	112432		Nut
96	Y052721			Nut, Terminal Block Plate
97	Y052734			Nut, Carrage Bolts And Bracket
98	053206		Not Available	SET SCREW, 3/8 X 3/8
99	053510		Not Available	SET SCREW, 3/8 X 5/8
100	054852		Not Available	LOCK WASHER, 3/16
101	Y054858	486009		Lockwasher
102	054873		Not Available	SPLIT LOCK WASHER FOR CLAMPING

the laundry company[®]