

Maytag 67C 03 - FRONT VIEW



[Maytag Residential Maytag 67C Dryer Parts Parts Diagram 03 - FRONT VIEW](#)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	300588		Not Available	PANEL COVER
2	300589		Not Available	TOP COVER
3	300592		Not Available	HINGE
4	300595		Not Available	KNOB AND DIAL
5	300596			Door Switch
6	300834		Not Available	BASE FRAME
7	300838			Lint Screen
8	Y300858	305865		High Limit Thermostat-W
9	305864			Thermostat Kit
11	Y301007			Thermostat
12	301023			Lint Screen Retainer
13	301057			Temperature Switch
14	301064		Not Available	BRACKET , CONTROLS ASSY.
15	301102			Timer
16	301121		Not Available	CABINET
17	301211		Not Available	BASE FRAME

18	301317		Not Available	CONTROL PANEL
19	301369		Not Available	SHAFT WITH SPIDER
20	Y301414	33301414		Timer
21	Y301414	33301414		Timer
22	301457			Door-White
23	302984			Baffle Assembly - Poly
24	303209			Button Kit For 3-1057
25	Y304585			Timer Motor RPR For 305214 Timer Only
26	310207			Screw, No.6 X 1/4 Inch
27	310217		Not Available	No Longer Available
28	310219			No.10z Fastener
29	310551			Fastener
30	310578		Not Available	WASHER
31	310579		Not Available	SCREW, No.10-24 X 11/16 INCH
32	Y310632	1163839		Screw
33	310703		Not Available	SCREW, No.10-24 X 3/8 INCH
34	310774		Not Available	CABINET TRIM
35	310775		Not Available	TRIM RETAINER
37	Y310780			Strike Button
38	310844	W10068250		Screw
39	Y302699	22003428		Leg, Adjustable
40	310935		Not Available	FASTENER
41	311007		Not Available	BACK FOR CABINET
42	311051		Not Available	SWITCH BRACKET
43	Y303541			Door Latch Bracket Kit
44	311052		Not Available	SWITCH LEVER
45	311091		Not Available	PIN
47	311298	4391991		Switch-Inf
48	311387		Not Available	CONTROL KNOB
49	Y311413			Dyalon Washer
50	311414			Latch Bracket
51	311447		Not Available	KNOB FOR DOOR
52	Y311499	W10068260		Screw
53	311944	Y311946		Heater Wire 240 Volt
54	Y312060		Not Available	SHIELD FOR SPIDER---C
55	312207		Not Available	TERMINAL COVER
56	312231		Not Available	DOOR SEAL
57	210198			Fastener
58	210294	910309		Washer, Mounting Strap
59	210385			Lock Nut For Adjustable Leg
60	210442		Not Available	WASHER NYLON
61	210609			Nylon Washer
62	210684			Foot, Adjustable Leg
63	210830		Not Available	MEDALLION
64	210865		Not Available	FASTENER
65	210879		Not Available	SCREW, No.8 X 1/2 INCH
66	210970		Not Available	V BELT - 50 HZ
67	211114		Not Available	RETAINER FOR TRIM
68	211196			Acorn Nut
69	211343		Not Available	SPRING FASTENER
70	211586		Not Available	SCREW, No.8 X 7/8 INCH

71	211587	Not Available	SCREW, No.8 X 1/4 INCH
72	211739		Screw, Cabinet To Base
73	211970	Not Available	SCREW-TOP COVER TO CABINET
74	213077	Not Available	CAP FOR TIMER KNOB
75	Y014872		Screw, Coin Meter Stop -
76	038766	Not Available	HOLE SAW W/DRILL BIT
77	052792		Screw, 1 1/4-20 X 5/16
78	054580	Not Available	SCREW, No.10-32 X 1/4
79	Y059128		Standard 4" Vent Kit
80	Y059129	4396007RW	Vent Hood
81	Y059130		Pipe, Venting
82	Y059131		Elbow, Venting
83	059133	Not Available	ALUMINUM WINDOW 4X12X18
84	Y059134		PLATE, ALUM. WINDOW (15``X20``)

