



[Maytag Residential Maytag 70C Dryer Parts](#) Parts Diagram 06 - WIRING & CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y300059		Not Available	MICRO SWITCH---NA
2	300252		Not Available	SOCKET FOR PILOT LAMP
3	300254		Not Available	THERMOSTAT
4	300262		Not Available	TIMER
5	300268			High Limit Thermostat
6	300275		Not Available	WIRE HARNESS, MOTOR
7	300276		Not Available	WIRE HARNESS, CABINET
8	300278		Not Available	TERMINAL BLOCK
9	300280		Not Available	WIRE W/TERMINALS
13	300304	303650		Valve-Inlet
14	300314		Not Available	WIRE W/TERMINALS
19	Y301117		Not Available	MOTOR CORD
20	310154		Not Available	TERMINAL FOR MOTOR
21	310289		Not Available	TERMINAL FOR DRUM LIGHT WIRE
22	Y311916	22003781		Screw, Ground Strap
23	200046		Not Available	CONNECTOR, FEMALE

24	200272	Not Available	CONNECTOR, 3 WIRE
25	210175	Not Available	WIRE CONNECTOR
26	211737	248562	Terminal

