



[Maytag Residential Maytag 740C Dryer Parts](#) Parts Diagram 07 - WIRING & CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y300059		Not Available	MICRO SWITCH---NA
2	300268			High Limit Thermostat
3	300275		Not Available	WIRE HARNESS, MOTOR
4	300278		Not Available	TERMINAL BLOCK
5	300280		Not Available	WIRE W/TERMINALS
6	300290		Not Available	TIMER
7	300304	303650		Valve-Inlet
8	300314		Not Available	WIRE W/TERMINALS
9	300422		Not Available	WIRE HARNESS
10	300424	3370639		Caster
11	304586		Not Available	TIMER MOTOR
12	300551			Thermostat
13	300552		Not Available	LAMP SOCKET
14	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
15	310154		Not Available	TERMINAL FOR MOTOR

16	310289		Not Available	TERMINAL FOR DROM LIGHT WIRE
17	Y311916	22003781		Screw, Ground Strap
18	200046		Not Available	CONNECTOR, FEMALE
19	200272		Not Available	CONNECTOR, 3 WIRE
20	210175		Not Available	WIRE CONNECTOR
21	211737	248562		Terminal

