


Maytag 7MMGDC300YW1 02 - CABINET PARTS



Maytag [Residential Maytag 7MMGDC300YW1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3390631			Screw, 10-16 X 3/8
2	343641	681414		Screw, 10AB X 1/2
3	693995			Screw, Hex Head
4	W10236073			Bracket, Cabinet
5	3396795			Cover, Terminal Block
6	3404162			Clamp, Motor
7	3396805	280043		Panel-Rear
8	3403630			Plug, Strike Hole
9	3980175			Clamp, Elbow
10	3406107			Door Switch Assembly
11	697773	3395530		Screw
12	W10440460			Cord, Power
13	341029			Clamp, Pipe Door Spring
14	3404413			Plug, Hinge Hole
15	3394083			Clip, Front Panel
16	3392100	49621		Feet-Leveling

NI	279810		Foot-Optional
17	W10121316		Plug, Multivent
18	W10224934		Cabinet
19	98234		Clip, U-Bend
20	690363	18776	Lock, Front Top
21	W10224857	W10242624	Panel
22	8066217		Hinge, Top
23	685203	279220	Clip
24	3389441		Door Catch Assembly
25	3405246		Seal, Door Push-To-Start
26	691366		Idler And Pulley Assembly
27	342055	488627	Screw
28	W10362431		Hinge And Pin Assembly
29	8066206	279827	Motor-Drive
30	8066184		Pulley, Motor
31	W10198086		Belt, Drive
32	3400500		Bolt, 3405245 5/16-18 X 3/4
33	3403431		Strike, Panel
34	348780		Base, Motor
35	3402341		Door, Inner
36	3402335		Door, Front
37	8565970		Handle, Door
38	3406129		Seal And Bearing Assembly
39	8564457		Plug, Front Panel
40	W10336852	W10465748	Burner-Gas
41	W10316529		Foam-Seal Cabinet
42	W10316619		Seal, Spill Guard Foam
43	3390647	488729	Screw

the laundry company[®]

the laundry company[®]