


Maytag 7MMPD6845TM0 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Model: 7MMPD6845TM0
(White/Metallic)



W10122839

5

Maytag [Residential Maytag 7MMPD6845TM0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8575076	8575076A		Dispenser
2	3354733	W10074580		Cap, Barrier
3	3348855	W10072840		Fabric Softener
4	358237			Screw And Washer
5	3949550			Washer
6	W10093696			Agitator
7	3951682	285809		Cam-Agitator
8	3366877	80040		Dog-Agitator
9	3952374			Bearing, Driven Cam
10	3363003			Mover, Clothes
11	3951608			Spacer, Thrust
12	W10093695			Agitator
13	W10093698			Tub Ring And Gasket
14	3976308			Gasket, Tub Ring
15	3354845			Clip, Agitator
16	8543666			Washer, Agitator

17	8519788	387240	Ring, Balance
18	21366		Nut, Spanner
19	8526016	W10389328	Clothes Container, Assembly
20	2219077		Clip, Pressure Switch Hose
21	3347780	353244	Hose, Pressure Switch
22	389140		Tub Block, Basket Drive
23	63849		Strain Relief, Power Cord
24	383727		Gasket, Centerpodt

