


# Maytag 7MWGD1602AW0 01 - TOP AND CONSOLE PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

12-11 Litho in U.S.A. (BMN) (psw)

1

Part No. W10471362 Rev. A

Maytag [Residential Maytag 7MWGD1602AW0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10329763		Not Available	INSTRUCTIONS, INSTALLATION
"	W10454973		Not Available	USE & CARE GUIDE
"	8578889		Not Available	Wiring Diagram
2	<a href="#">W10117655</a>			Switch, Push-To-Start
3	<a href="#">694419</a>			Mini-Buzzer
4	8566035	<a href="#">8565957</a>		Cap, End
5	<a href="#">W10034750</a>			Timer Knob Assembly
6	<a href="#">W10103406</a>			Panel, Rear Console
7	<a href="#">8530169</a>			Switch, Temperature
8	8566032	<a href="#">8565954</a>		Cap, End
9	<a href="#">693995</a>			Screw, Hex Head
10	<a href="#">8557857</a>			Screen, Lint
11	<a href="#">8536939</a>			Clip, Knob
12	3348629	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
13	688082	<a href="#">487210</a>		Screw, For Mtg. Service

13	<a href="#">000903</a>	<a href="#">407240</a>	Capacitor
14	<a href="#">8312709</a>		Clip-Console
15	<a href="#">W10450282</a>		Harness, Wiring
16	8559800	<a href="#">8563663</a>	Top
17	359625	<a href="#">487240</a>	Screw, For Mtg. Service Capacitor
18	<a href="#">W10034380</a>		Knob, Control
19	<a href="#">3405156</a>		Switch, Rotary
20	<a href="#">3400818</a>		Screw, Timer Mounting
21	<a href="#">8566184</a>		Timer Assembly
22	<a href="#">8558178</a>		Control, Electronic
23	W10452090	Not Available	PANEL & CONSOLE ASSEMBLY
24	<a href="#">W10123956</a>		Dampening Panel
25	<a href="#">W10113080</a>		Wire, Jumper
26	<a href="#">8566052</a>		Bracket, Console

