


Maytag 7MWGD1730YW1 01 - TOP AND CONSOLE PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

11-11 Litho in U.S.A. (BMN)(day)

1

Part No. W10460955 Rev. A

Maytag [Residential Maytag 7MWGD1730YW1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10329763		Not Available	INSTRUCTIONS, INSTALLATION
"	W10368973		Not Available	USE & CARE GUIDE
"	W10118081		Not Available	Wiring Diagram
2	W10117655			Switch, Push-To-Start
3	694419			Mini-Buzzer
4	8566035	8565957		Cap, End
5	W10034750			Timer Knob Assembly
6	W10103406			Panel, Rear Console
7	8530169			Switch, Temperature
8	8566032	8565954		Cap, End
9	693995			Screw, Hex Head
10	8557857			Screen, Lint
11	8536939			Clip, Knob
12	3348629	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
13	688082	487210		Screw, For Mtg. Service

13	000903	407440	Capacitor
14	8312709		Clip-Console
15	8576542	W10071310	Harns-Wire
16	8559800	8563663	Top
17	359625	487240	Screw, For Mtg. Service Capacitor
18	W10034380		Knob, Control
19	3405156		Switch, Rotary
20	3400808		Screw. Mounting
21	8566184		Timer Assembly
22	8558178		Control, Electronic
23	W10354023		Panel And Console Assembly
24	W10123956		Dampening Panel
25	W10113080		Wire, Jumper
26	8566052		Bracket, Console

