


Maytag 7MWGD1730YW1 02 - CABINET PARTS



Maytag Residential Maytag 7MWGD1730YW1 Dryer Parts Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8533974	4331106		Screw, No.10-32 X 7/16
2	343641	681414		Screw, 10AB X 1/2
3	693995			Screw, Hex Head
4	W10236073			Bracket, Cabinet
5	3396795			Cover, Terminal Block
6	3404162			Clamp, Motor
7	3396805	280043		Panel-Rear
8	3390647	488729		Screw
9	3980175			Clamp, Elbow
10	3406107			Door Switch Assembly
11	697773	3395530		Screw
12	341029			Clamp, Pipe Door Spring
13	3357011	308685		Side Trim)
14	W10041960			Spring, Door
15	8066217			Hinge, Top
16	3392100	49621		Feet-Leveling

NI	279810		Foot-Optional
17	342043	486146	Screw
18	8530603	8533643	Cabinet
19	98234		Clip, U-Bend
20	690363	18776	Lock, Front Top
21	3395197	279740	Panel
22	W10121316		Plug, Multivent
23	685203	279220	Clip
24	3389441		Door Catch Assembly
25	3390731		Seal, Door
26	337189		Clip, Hinge
27	342055	488627	Screw
28	8066056		Hinge, Door
"	8066057		Hinge, Door
29	8066206	279827	Motor-Drive
30	8066184		Pulley, Motor
31	3400500		Bolt, 3405245 5/16-18 X 3/4
32	348780		Base, Motor
33	696144	279570	Latch
34	W10131364	341241	Belt
35	695737		Door, Rear
36	3393549		Door, Front
37	W10095180		Handle, Door
38	3406129		Seal And Bearing Assembly
39	8564457		Plug, Front Panel
40	691366		Idler And Pulley Assembly
41	W10440460		Cord, Power
42	3394083		Clip, Front Panel
43	W10336852	W10465748	Burner-Gas
44	3390631		Screw, 10-16 X 3/8

