



[Maytag Residential Maytag A101 Washer Parts](#) Parts Diagram 03 - ELECTRICAL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200046		Not Available	CONNECTOR, FEMALE
2	200729			Timer
3	200733		Not Available	SWITCH-TEMPERATURE CONTROL
4	200977			Solenoid For Water Valve
5	200996		Not Available	TIMER MOTOR, A
6	201012		Not Available	ESCAPEMENT FOR TIMER
7	201124		Not Available	UNBALANCE LEVER
8	201807	12002353		Motor-Drve
9	Y201808			Converter
10	201809			Lid Switch
11	201956		Not Available	MOTOR CORD
13	201491			Temperature Switch
14	210175		Not Available	WIRE CONNECTOR
15	211065			Spring, Index Wheel
16	211091		Not Available	TIMER DIAL
17	211092		Not Available	CAP, KNOB

18	211093	Not Available	RETAINER
19	211120		Knob, Timer
20	211251		Screw, Transformer
21	212715	Not Available	KNURLED NUT FOR TEMP. SWITCH

