

Maytag A101 04 - FRONT VIEW



[Maytag Residential Maytag A101 Washer Parts](#) Parts Diagram 04 - FRONT VIEW
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200555		Not Available	AGITATOR
2	200725		Not Available	HINGE FOR LID
3	200729			Timer
4	200733		Not Available	SWITCH-TEMPERATURE CONTROL
5	200746		Not Available	WATER VALVE----NA
6	201807	12002353		Motor-Drve
7	201809			Lid Switch
8	201814		Not Available	TOP COVER, PORCELAIN
9	201956		Not Available	MOTOR CORD
10	202055		Not Available	COVER FOR CONTROL PANEL
11	202292		Not Available	CABINET
13	201491			Temperature Switch
14	210609			Nylon Washer
15	210684			Foot, Adjustable Leg
16	210865		Not Available	FASTENER

17	210879		Not Available	SCREW, No.8 X 1/2 INCH
18	210995		Not Available	BACK PANEL
19	211062		Not Available	RUBBER BUMPER
20	211065			Spring, Index Wheel
21	211091		Not Available	TIMER DIAL
22	211092		Not Available	CAP, KNOB
23	211093		Not Available	RETAINER
24	211113		Not Available	TRIM MOULDING
25	211114		Not Available	RETAINER FOR TRIM
26	211118		Not Available	CONTROL PANEL
27	211120			Knob, Timer
28	211196			Acorn Nut
29	211251			Screw, Transformer
30	211500			Washer, Bracket To Top Cover
31	211501		Not Available	GASKET FOR LID HINGE
32	211738		Not Available	SPRING FASTENER
33	211739			Screw, Cabinet To Base
34	211792		Not Available	PIN
35	211794		Not Available	SCREW-LID SWITCH TO BRACKET
36	211881			Grommet, Cord Part Not Used- Gas Models Only
37	211970		Not Available	SCREW-TOP COVER TO CABINET
38	212014		Not Available	MEDALLION
39	212033		Not Available	LID
40	212138		Not Available	FASTENER, PANEL TO TOP COVE
42	212715		Not Available	KNURLED NUT FOR TEMP. SWITCH
43	310219			No.10z Fastener
44	Y310376			Clip, Door Switch Harness
45	Y310632	1163839		Screw
46	310934	22003428		Leg, Adjustable
47	311434	31-1434		Miniman
48	Y311499	W10068260		Screw
49	Y014872			Screw, Coin Meter Stop -

