

Maytag A102 05 - FRONT VIEW



[Maytag Residential Maytag A102 Washer Parts](#) Parts Diagram 05 - FRONT VIEW

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	200555		Not Available	AGITATOR
3	200746		Not Available	WATER VALVE---NA
4	200996		Not Available	TIMER MOTOR, A
5	201012		Not Available	ESCAPEMENT FOR TIMER
6	201124		Not Available	UNBALANCE LEVER
7	201781			Temperature Switch
9	201792			Control Panel
10	201805	12002351		Motor-Drve
11	201956		Not Available	MOTOR CORD
13	201985		Not Available	WIRE HARNESS
14	202055		Not Available	COVER FOR CONTROL PANEL
15	202292		Not Available	CABINET
16	Y202734	215058		Pad, Cabinet Bumper
17	202770	279347		Switch-Lid
18	202923			Timer
20	204722		Not Available	BUTTON KIT FOR 2-1781

21	210385		Lock Nut For Adjustable Leg
22	210442	Not Available	WASHER NYLON
23	210609		Nylon Washer
24	210684		Foot, Adjustable Leg
25	210865	Not Available	FASTENER
26	210866		Nut, Twin Speed
27	210879	Not Available	SCREW, No.8 X 1/2 INCH
28	210995	Not Available	BACK PANEL
29	211065		Spring, Index Wheel
30	211113	Not Available	TRIM MOULDING
31	211114	Not Available	RETAINER FOR TRIM
32	211225	Not Available	PAD FOR UNBALANCE BUMPER
33	211251		Screw, Transformer
34	211500		Washer, Bracket To Top Cover
35	211586	Not Available	SCREW, No.8 X 7/8 INCH
36	214697		Easy-Grip Knob
37	211587	Not Available	SCREW, No.8 X 1/4 INCH
38	211605		Bezel, Timer Dial
39	211726		Hinge, Ball Lid
40	211738	Not Available	SPRING FASTENER
41	211739		Screw, Cabinet To Base
42	211835	Not Available	CONTROL KNOB - TIMER
43	211881		Grommet, Cord Part Not Used-Gas Models Only
44	211970	Not Available	SCREW-TOP COVER TO CABINET
45	212014	Not Available	MEDALLION
46	212027		Timer Dial-Gray
47	212073		LID (WHITE)
48	212138	Not Available	FASTENER, PANEL TO TOP COVE
49	212220	213501	Screw, No.6-20 X 1-1/8 Inch
50	212628	Not Available	SCREW & WASHER
51	212716		Bumper, Lid
52	212812	Not Available	TOP COVER, PORCELAIN
53	212813		Pin For Lid Switch
54	212814	204968	Plunger And Bracket Assembly--W
55	213077	Not Available	CAP FOR TIMER KNOB
56	310219		No.10z Fastener
57	Y310376		Clip, Door Switch Harness
58	Y310632	1163839	Screw
59	310934	22003428	Leg, Adjustable
60	053759	25-7614	Screw
61	Y057937	350930	Paint, Pressurized Spray B