

Maytag A103 05 - FRONT VIEW



[Maytag Residential Maytag A103 Washer Parts](#) Parts Diagram 05 - FRONT VIEW

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	200555		Not Available	AGITATOR
3	200746		Not Available	WATER VALVE---NA
4	201124		Not Available	UNBALANCE LEVER
5	201747		Not Available	CONTROL PANEL
6	201750			Timer RPR
7	201754		Not Available	PRESSURE SWITCH
9	201781			Temperature Switch
11	201805	12002351		Motor-Drve
12	201956		Not Available	MOTOR CORD
13	202055		Not Available	COVER FOR CONTROL PANEL
14	202247			Wire Harness
15	202292		Not Available	CABINET
16	Y202734	215058		Pad, Cabinet Bumper
17	202770	279347		Switch-Lid
18	204716		Not Available	BUTTON KIT FOR 2-1754
20	204722		Not Available	BUTTON KIT FOR 2-1781

21	210175	Not Available	WIRE CONNECTOR
22	210442	Not Available	WASHER NYLON
23	210609		Nylon Washer
24	210684		Foot, Adjustable Leg
25	210865	Not Available	FASTENER
26	210866		Nut, Twin Speed
27	210879	Not Available	SCREW, No.8 X 1/2 INCH
28	210995	Not Available	BACK PANEL
29	211065		Spring, Index Wheel
30	211113	Not Available	TRIM MOULDING
31	211114	Not Available	RETAINER FOR TRIM
32	211168	W10139210	Screw, 8-18 X 5/16
33	211251		Screw, Transformer
34	211500		Washer, Bracket To Top Cover
35	214697		Easy-Grip Knob
36	211586	Not Available	SCREW, No.8 X 7/8 INCH
37	211587	Not Available	SCREW, No.8 X 1/4 INCH
38	211605		Bezel, Timer Dial
39	211726		Hinge, Ball Lid
40	211737	248562	Terminal
41	211738	Not Available	SPRING FASTENER
42	200739	Not Available	GEAR HOUSING
43	211835	Not Available	CONTROL KNOB - TIMER
44	211881		Grommet, Cord Part Not Used- Gas Models Only
45	211970	Not Available	SCREW-TOP COVER TO CABINET
46	212008	Not Available	TIMER DIAL
48	212014	Not Available	MEDALLION
49	212062	Not Available	RECTANGULAR PLUG
50	212073		LID (WHITE)
51	212138	Not Available	FASTENER, PANEL TO TOP COVE
52	212220	213501	Screw, No.6-20 X 1-1/8 Inch
53	212336	Not Available	SCREW, No.8 X 3/4 INCH
54	212628	Not Available	SCREW & WASHER
55	212716		Bumper, Lid
56	212800	Not Available	TINNERMAN
57	212812	Not Available	TOP COVER, PORCELAIN
58	212813		Pin For Lid Switch
59	212814	204968	Plunger And Bracket Assembly--W
60	213077	Not Available	CAP FOR TIMER KNOB
61	310219		No.10z Fastener
62	Y310376		Clip, Door Switch Harness
63	Y310632	1163839	Screw
64	310934	22003428	Leg, Adjustable
65	053759	25-7614	Screw