



Maytag [Residential Maytag A103 Washer Parts](#) Parts Diagram 07 - POWER UNIT & CENTER ASSEMBLY  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200555		Not Available	AGITATOR
2	200730	<a href="#">22002124</a>		Shaft- Agi
3	200739		Not Available	GEAR HOUSING
4	200750		Not Available	GEAR CASE COVER
5	200824	<a href="#">6-2040130</a>		Tub Bearin
6	<a href="#">201189</a>			Lower Transmission Housing
7	201537	<a href="#">6-2095720</a>		Mounting S
8	202521	<a href="#">6-2095720</a>		Mounting S
9	204012	<a href="#">6-2095720</a>		Mounting S
10	204013	<a href="#">6-2040130</a>		Tub Bearin
11	210049	<a href="#">204966</a>		Gear Kit-Bakelite Agitator
12	<a href="#">204966</a>			Gear Kit-Bakelite Agitator
13	214276		Not Available	WASHER FOR GEARS
14	210052	<a href="#">7501P061-60</a>		Valve Ove
15	<a href="#">210054</a>			Pinion
16	<a href="#">210172</a>			Lock Washer

17	<a href="#">210179</a>		Retaining Ring
18	<a href="#">210183</a>		Groove Pin
19	<a href="#">210286</a>		Seal
20	<a href="#">210315</a>		Pinion
21	210454	Not Available	BOLT
22	210610	Not Available	STUD FOR SEGMENT
23	210611	Not Available	STUD-INTERMEDIATE GEAR
24	210612	Not Available	STUD-PITMAN
25	210632	<a href="#">22210632</a>	Gasket
26	<a href="#">210670</a>		Segment
27	211022	Not Available	BEARING
28	211028	<a href="#">22001586</a>	Deflector, Water
29	211047	<a href="#">6-2110472</a>	Nut- Clamp
30	<a href="#">211089</a>		Lug, Stop Pulley
31	211090	<a href="#">22003555</a>	Washer, Stop Lug
32	<a href="#">211130</a>		Bearing Liner, Tub Bearing
33	<a href="#">211210</a>		Washer, Clamping Nut
34	211375	<a href="#">681582</a>	Screw
35	211483	<a href="#">6-2114830</a>	Washer- SP
36	<a href="#">211484</a>		Washer, Lug
37	<a href="#">211485</a>		Center Shaft
38	<a href="#">211486</a>		Screw, 3/8-16 X 1/2 Inch
39	<a href="#">211487</a>		Groov-Pin
40	211618	<a href="#">22001423</a>	Set Screw, Mounting Stem
41	211717	Not Available	WRIST PIN
42	211837	Not Available	SPRING FOR TUB SEAL
43	Y0A4298	<a href="#">6-0A57420</a>	Seal- Agitator
44	0A4731	Not Available	SPLINE
45	14792	<a href="#">WH1X2296</a>	Friction Pad
46	<a href="#">Y014827</a>		Washer-Center Shaft
47	<a href="#">Y015149</a>		Brass Washer-Agitator Seal
48	<a href="#">Y015494</a>		Stop Ring-Agitator Shaft
49	<a href="#">Y015629</a>		Bolt, Grinding Chamber
50	<a href="#">015639</a>		Dowel Pin
51	<a href="#">Y015666</a>		Washer, Retaining -
52	<a href="#">Y015667</a>		Retaining Ring
53	<a href="#">Y015902</a>		Spring For Agitator
54	052836	Not Available	CAP SCREW, 3/8-16 X 1
55	<a href="#">Y053241</a>		Set Screw, Motor Pulley
56	<a href="#">Y053241</a>		Set Screw, Motor Pulley
57	Y054866	<a href="#">486009</a>	Lockwasher
58	Y055977		TURBINE OIL, 4 OZ.
59	<a href="#">Y055978</a>		Rubber Adhesive, 2 Oz Tube
60	<a href="#">Y055980</a>		Hi-Temp Adhesive, 2 Oz Tube
61	<a href="#">Y056016</a>		Center Seal Grease
62	Y056080	<a href="#">6-0560800</a>	Oil
63	038313	<a href="#">22038313</a>	Wrench, Spanner
64	<a href="#">205811</a>		Counterweight
65	Y052740	<a href="#">62739</a>	Nut, Lock