



Maytag [Residential Maytag A107 Washer Parts](#) Parts Diagram 15 - REAR VIEW (ORIGINAL)  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	203172		Not Available	TOP COVER-WHITE
2	203177	<a href="#">205613</a>		Water Valve
3	203319	<a href="#">22203319</a>		Cabinet
4	<a href="#">204590</a>			Cord, Power
5	205003		Not Available	CONTROL PANEL
6	205160		Not Available	TOP COVER-WHITE
7	205192		Not Available	CONTROL PANEL, SUN-GLOW
8	205197		Not Available	CONTROL PANEL KIT, SUN-GLOW
9	<a href="#">210385</a>			Lock Nut For Adjustable Leg
10	<a href="#">210684</a>			Foot, Adjustable Leg
11	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
12	211878		Not Available	PLATE, ACCESS
13	<a href="#">211881</a>			Grommet, Cord Part Not Used-Gas Models Only
14	212276	<a href="#">W10116760</a>		Screw

15	<a href="#">212277</a>		Screw, No.8 X 1/2 Inch
16	<a href="#">212984</a>		Valve Mounting Plate
17	212985	<a href="#">22002924</a>	Plate, Access
18	213009	Not Available	CONTROL COVER-WHITE
19	213121	<a href="#">3400111</a>	Screw, 12-14 X 5/8
20	214135	Not Available	CLIP, FASTENER
21	214135	Not Available	CLIP, FASTENER
22	214337	<a href="#">96160</a>	Screen
23	214519		LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
24	Y302699	<a href="#">22003428</a>	Leg, Adjustable
25	<a href="#">312620</a>		Screw, Sems

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>