



[Maytag Residential Maytag A107 Washer Parts](#) Parts Diagram 16 - TOP COVER UP (PRIOR TO SERIES 02)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200846			Clamp - Tub Cover
2	201523		Not Available	INNER TUB
3	201765		Not Available	COVER, TUB
4	202515	596669		Clamp, Manifold
5	Y202734	215058		Pad, Cabinet Bumper
6	202770	279347		Switch-Lid
7	203172		Not Available	TOP COVER-WHITE
8	203318		Not Available	OUTER TUB
9	203319	22203319		Cabinet
10	204445			Screw And Fastener Assembly
11	204968			Plunger And Bracket Assembly--W
12	205006			Major Wire Harness
13	210866			Nut, Twin Speed
14	211223			Bumper, Unbalance
15	211232			Seal, Tub Cover
16	212073			LID (WHITE)

17	212220	213501	Screw, No.6-20 X 1-1/8 Inch
18	212716		Bumper, Lid
19	212937	Not Available	BARRIER, MOISTURE
20	212942	22001619	Tube, Water Level Switch
21	213013		Hose, Injector
22	213015		Nozzle, Injector
23	213016	216201	Nozzle
24	213055	206154	Injector Tube With Seal
25	213057	22213057	Sleeve- In
26	213718		Plunger, Lid Switch
27	213719	Not Available	LEVER, UNBALANCE
28	213720		Spring, Lid Switch
29	214135	Not Available	CLIP, FASTENER
30	410296	596669	Clamp, Manifold
31	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx

