



[Maytag Residential Maytag A108 Washer Parts](#) Parts Diagram 01 - AGITATOR & ACCESSORIES
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	Y015494			Stop Ring-Agitator Shaft
2	203320		Not Available	LINT FILTER - DISPENSER
3	205054		Not Available	AGITATOR
4	212815		Not Available	DISPENSER CUP

