

**No Document
Available**

[Maytag Residential Maytag A108S Washer Parts](#) Parts Diagram 01 - AGITATOR & ACCESSORIES
[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|-------------|---------------|--------------------------|
| 1 | Y015494 | | | Stop Ring-Agitator Shaft |
| 2 | 203320 | | Not Available | LINT FILTER - DISPENSER |
| 3 | 205054 | | Not Available | AGITATOR |
| 4 | 212815 | | Not Available | DISPENSER CUP |