



Maytag [Residential Maytag A108S Washer Parts](#) Parts Diagram 12 - POWER UNIT & CENTER ASSEMBLY
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y0A4298	6-0A57420		Seal- Agitator
2	Y014792	6-0A57420		Seal- Agitator
3	Y014827			Washer-Center Shaft
4	Y014839			Collar-Drive Shaft
5	Y015149			Brass Washer-Agitator Seal
6	Y015494			Stop Ring-Agitator Shaft
7	Y015629			Bolt, Grinding Chamber
8	015639			Dowel Pin
9	Y015666			Washer, Retaining -
10	Y015667			Retaining Ring
11	Y015902			Spring For Agitator
12	038313	22038313		Wrench, Spanner
13	Y038555			Tool-Install Center Shaft
14	Y054867			Washer, Lock
15	Y056016			Center Seal Grease
16	Y056080	6-0560800		Oil

17	200730	22002124		Shaft- Agi
18	200750		Not Available	GEAR CASE COVER
19	200813		Not Available	GEAR CASE COVER ASSEMBLY
20	200824	6-2040130		Tub Bearin
21	201463		Not Available	PITMAN WITH WRIST PIN
22	201537	6-2095720		Mounting S
23	202521	6-2095720		Mounting S
24	203162			Gear Housing W/Studs And Tube
25	203775			Ctn 10 Auto Trans Lube
26	204012	6-2095720		Mounting S
27	204013	6-2040130		Tub Bearin
28	204437	W10172458		Transmison
29	204967			Gear Kit-Power Fin Agitator
30	210054			Pinion
31	210179			Retaining Ring
32	210183			Groove Pin
33	210286			Seal
34	210315			Pinion
35	210632	22210632		Gasket
36	210670			Segment
37	210690			Seal, Rubber
38	211100			Washer, Outer Tub
39	211130			Bearing Liner, Tub Bearing
40	211210			Washer, Clamping Nut
41	211375	681582		Screw
42	211483	6-2114830		Washer- SP
43	211484			Washer, Lug
44	211486			Screw, 3/8-16 X 1/2 Inch
45	211487			Groov-Pin
46	211618	22001423		Set Screw, Mounting Stem
47	211837		Not Available	SPRING FOR TUB SEAL
48	212988			Part Not Used
49	213068	204967		Gear Kit-Power Fin Agitator
50	214276		Not Available	WASHER FOR GEARS

