



Maytag [Residential Maytag A108S Washer Parts](#) Parts Diagram 16 - TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200846			Clamp - Tub Cover
2	201523		Not Available	INNER TUB
3	201765		Not Available	COVER, TUB
4	202515	596669		Clamp, Manifold
5	Y202734	215058		Pad, Cabinet Bumper
6	203319	22203319		Cabinet
7	203320		Not Available	LINT FILTER - DISPENSER
8	204445			Screw And Fastener Assembly
9	204968			Plunger And Bracket Assembly--W
10	205054		Not Available	AGITATOR
11	205160		Not Available	TOP COVER-WHITE
12	205161	489503		Clamp
13	205218		Not Available	OUTER TUB ASSEMBLY
14	211232			Seal, Tub Cover
15	211726			Hinge, Ball Lid
16	212073			LID (WHITE)

17	212716		Bumper, Lid
18	212815	Not Available	DISPENSER CUP
19	212937	Not Available	BARRIER, MOISTURE
20	212942	22001619	Tube, Water Level Switch
21	213013		Hose, Injector
22	213015		Nozzle, Injector
23	213055	206154	Injector Tube With Seal
24	213718		Plunger, Lid Switch
25	213719	Not Available	LEVER, UNBALANCE
26	213720		Spring, Lid Switch
27	214135	Not Available	CLIP, FASTENER
28	214376	22002331	Spacer, Front Panel
29	214436		Gasket
30	214437	215577	Bleach Inlet White
31	214495		Tube, Inlet To Tub
32	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx

