



[Maytag Residential Maytag A112 Washer Parts Parts Diagram 01 - 50HZ PARTS](#)  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	202157	<a href="#">12002352</a>		Motor-Drve
2	<a href="#">Y202496</a>			Pulley, Motor
3	<a href="#">211948</a>			V Belt, DriVe Pulley
4	<a href="#">211451</a>			Belt, Pump
5	<a href="#">201101</a>			Capacitor
6	<a href="#">211149</a>			Clip, Capacitor
7	Y205684		Not Available	WATER VALVE 240-50
8	<a href="#">203237</a>			No.17 Wire With Terminal
9	<a href="#">206688</a>			Timer 240-50
10	<a href="#">206256</a>			Timer - 240-50
11	206257		Not Available	TIMER - 240-50----NA
12	<a href="#">205035</a>			Timer Motor 240-50
13	206689		Not Available	WIRE HARNESS