


Maytag A17CA 10 - CONTROL PANELS



Maytag [Residential Maytag A17CA Washer Parts](#) Parts Diagram 10 - CONTROL PANELS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SCREW (No.6-32 X 3/8)
002	NLA		Not Available	TOP COVER-WHITE
003	203971	203970		Switch, Water Level
004	204051	22204051		Knob
005	NLA		Not Available	CONTROL COVER-WHITE
006	204109			Light, Signal
007	204510			Fabric Control Switch
008	NLA		Not Available	CONTROL PANEL WITH LENS
009	NLA		Not Available	MAIN WIRE HARNESS
010	NLA		Not Available	MAIN WIRE HARNESS
011	NLA		Not Available	MAIN WIRE HARNESS
012	204968			Plunger And Bracket Assembly--W
013	205415	279347		Switch-Lid
014	210198			Fastener
015	210866			Nut, Twin Speed

016	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
017	211500		Washer, Bracket To Top Cover
018	211737	248562	Terminal
019	212276	W10116760	Screw
020	212519	488234	Screw 8-32 X 1/4
021	212937	Not Available	BARRIER, MOISTURE
022	213042	Not Available	PANEL, BACK
023	213099		Lens For Control Panel
024	213501		Screw, No.6-20 X 1-1/8 Inch
025	NLA	Not Available	LID BUMPER
026	213718		Plunger, Lid Switch
027	213719	Not Available	LEVER, UNBALANCE
028	213720		Spring, Lid Switch
029	213949		Screw, No.8-18 X 5/16 Inch
030	214135	Not Available	CLIP, FASTENER
031	214650		Screw For 2-4051 Knob
032	Y310632	1163839	Screw
033	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx

