


Maytag A18CA 04 - CONTROL PANELS



Maytag Residential Maytag A18CA Washer Parts Parts Diagram 04 - CONTROL PANELS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SCREW (No.6-32 X 3/8)
002	NLA		Not Available	TOP COVER-WHITE
003	203961	22004474		Switch- Pr
004	203961	22004474		Switch- Pr
005	204051	22204051		Knob
006	NLA		Not Available	CONTROL COVER-WHITE
007	204109			Light, Signal
008	204510			Fabric Control Switch
009	NLA		Not Available	CONTROL PANEL WITH LENS
010	NLA		Not Available	MAIN WIRE HARNESS
011	NLA		Not Available	MAIN WIRE HARNESS
012	NLA		Not Available	MAIN WIRE HARNESS
013	204968			Plunger And Bracket Assembly--W
014	205415	279347		Switch-Lid
015	210198			Fastener

016	210866		Nut, Twin Speed
017	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
018	211500		Washer, Bracket To Top Cover
019	211737	248562	Terminal
020	212276	W10116760	Screw
021	212519	488234	Screw 8-32 X 1/4
022	212937	Not Available	BARRIER, MOISTURE
023	213042	Not Available	PANEL, BACK
024	213099		Lens For Control Panel
025	213501		Screw, No.6-20 X 1-1/8 Inch
026	NLA	Not Available	LID BUMPER
027	213718		Plunger, Lid Switch
028	213719	Not Available	LEVER, UNBALANCE
029	213720		Spring, Lid Switch
030	213949		Screw, No.8-18 X 5/16 Inch
031	214135	Not Available	CLIP, FASTENER
032	214650		Screw For 2-4051 Knob
033	Y310632	1163839	Screw
034	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx

