


Maytag A18CM 03 - CM CONTROL CENTER



Maytag [Residential Maytag A18CM Washer Parts](#) Parts Diagram 03 - CM CONTROL CENTER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	NLA		Not Available	TIMER MOTOR, A
003	203188		Not Available	TIMER ACCESS DOOR (WHT)
004	NLA		Not Available	ACTUATOR KIT-WASHER SLIDES---N
005	NLA		Not Available	MTG. STRAP---NA
006	NLA		Not Available	HARNESS-SWITCH TO TIMER
007	NLA		Not Available	COIN DROP ASSEMBLY
008	NLA		Not Available	COIN BOX-WHITE---NA
009	NLA		Not Available	MAIN WIRE HARNESS
010	204577		Not Available	TIMER WITH KNOB AND PIN
011	NLA		Not Available	CONTROL CENTER-WHITE
012	204973			Motor, Timer
013	205415	279347		Switch-Lid
014	NLA		Not Available	MAYTAG COIN SLIDE

015	NLA		Not Available	COUNTER KIT WITH ACTUATOR
016	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
017	212220	213501		Screw, No.6-20 X 1-1/8 Inch
018	212276	W10116760		Screw
019	212707	3196385		Screw
020	212951			Screw, No.6-32 X 1/4 Inch
021	NLA		Not Available	GASKET UNDER CONTROL CENTER
022	213035			Bolt, Locking
023	NLA		Not Available	SPRING TENSION LEVER RETURN
024	NLA		Not Available	SPRING TENSION LEVER RETURN
025	NLA		Not Available	LEVER ARM FOR SWITCH
026	NLA		Not Available	MOUNTING BRACKET FOR TIMER
027	NLA		Not Available	OUTER CASE-WHITE
028	NLA		Not Available	COIN BOX COVER
029	910309			Washer, Mounting Strap

