


Maytag A18CM 07 - TRANSMISSION



Maytag [Residential Maytag A18CM Washer Parts](#) Parts Diagram 07 - TRANSMISSION
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y014827			Washer-Center Shaft
002	Y014839			Collar-Drive Shaft
003	Y015629			Bolt, Grinding Chamber
004	NLA		Not Available	DOWEL PIN
005	Y015902			Spring For Agitator
006	Y052740	62739		Nut, Lock
007	Y056080	6-0560800		Oil
008	200730	22002124		Shaft- Agi
009	NLA		Not Available	GEAR CASE COVER ASSEMBLY
010	NLA		Not Available	PITMAN WITH WRIST PIN
011	NLA		Not Available	GEAR HOUSING W/STUDS & TUBE
013	203438	W10172457		Transmison
014	203438	W10172457		Transmison
015	204967			Gear Kit-Power Fin Agitator
016	NLA		Not Available	COUNTERWEIGHT

017	210054		Pinion
018	NLA	Not Available	LOCK WASHER
019	NLA	Not Available	RETAINING RING
020	210183		Groove Pin
021	210286		Seal
022	210315		Pinion
023	210632	22210632	Gasket
024	NLA	Not Available	SEGMENT
025	210690		Seal, Rubber
026	211089		Lug, Stop Pulley
027	211090	22003555	Washer, Stop Lug
028	211375	681582	Screw
029	211483	6-2114830	Washer- SP
030	211484		Washer, Lug
031	211486		Screw, 3/8-16 X 1/2 Inch
032	NLA	Not Available	GROOV-PIN
033	213044		Shaft, Center
034	213044		Shaft, Center
035	NLA	Not Available	WASHER FOR GEARS

