


# Maytag A18CT 01 - FRONT VIEW



Maytag [Residential Maytag A18CT Washer Parts](#) Parts Diagram 01 - FRONT VIEW  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	TOP COVER-WHITE
002	NLA		Not Available	ACCESS DOOR (WHITE)
003	NLA		Not Available	CABINET-WHITE
004	NLA		Not Available	ACCESS DOOR (WHITE)
005	204051	<a href="#">22204051</a>		Knob
006	NLA		Not Available	CONTROL COVER-WHITE
007	<a href="#">204109</a>			Light, Signal
008	<a href="#">204439</a>			Screw And Fstner Assembly
009	<a href="#">204445</a>			Screw And Fastener Assembly
010	<a href="#">204510</a>			Fabric Control Switch
011	NLA		Not Available	CONTROL PANEL WITH LENS
012	NLA		Not Available	CONTROL CENTER-WHITE
013	NLA		Not Available	CONTROL CENTER-WHITE
014	NLA		Not Available	CONTROL CENTER-WHITE
015	<a href="#">204968</a>			Plunger And Bracket Assembly--W

016	205415	<a href="#">279347</a>		Switch-Lid
017	<a href="#">210198</a>			Fastener
018	<a href="#">210385</a>			Lock Nut For Adjustable Leg
019	<a href="#">210684</a>			Foot, Adjustable Leg
020	<a href="#">211726</a>			Hinge, Ball Lid
021	212519	<a href="#">488234</a>		Screw 8-32 X 1/4
022	<a href="#">212716</a>			Bumper, Lid
023	212982	<a href="#">22001650</a>		Fastener, Spring
024	212998		Not Available	PANEL, FRONT (WHT)
025	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
026	NLA		Not Available	GASKET UNDER CONTROL CENTER
027	NLA		Not Available	FRONT PLATE F/TICKET CONTRO
028	NLA		Not Available	GASKET UNDER CONTROL CENTER
029	<a href="#">213099</a>			Lens For Control Panel
030	NLA		Not Available	LATCH FOR ACCESS DOOR
031	NLA		Not Available	LID BUMPER
032	<a href="#">213949</a>			Screw, No.8-18 X 5/16 Inch
033	214000		Not Available	LID-WHITE
034	<a href="#">214650</a>			Screw For 2-4051 Knob
035	<a href="#">215058</a>			Pad, Cabinet Bumper
036	Y302699	<a href="#">22003428</a>		Leg, Adjustable

*the laundry company®*

*the laundry company®*