



[Maytag Residential Maytag A200 Washer Parts](#) Parts Diagram 01 - 115-230 VOLT, 50 CYCLE PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	202158		Not Available	MOTOR 120-50
2	<a href="#">Y202496</a>			Pulley, Motor
3	211709		Not Available	MOTOR STOP
4	<a href="#">211948</a>			V Belt, Drive Pulley
5	<a href="#">211451</a>			Belt, Pump
6	<a href="#">201408</a>			Capacitor 120-50
7	<a href="#">200977</a>			Solenoid For Water Valve
8	<a href="#">201090</a>			Timer
9	<a href="#">201003</a>			Timer Motor
10	201012		Not Available	ESCAPEMENT FOR TIMER
11	202157	<a href="#">12002352</a>		Motor-Drive
12	<a href="#">Y202496</a>			Pulley, Motor
13	211709		Not Available	MOTOR STOP
14	<a href="#">211948</a>			V Belt, Drive Pulley
15	<a href="#">211451</a>			Belt, Pump
16	<a href="#">201101</a>			Capacitor

17	201099	Not Available	VALVE 240-50
18	<a href="#">201848</a>		Solenoid 240-50
19	201104	Not Available	SOLENOID 240-50
20	201100	Not Available	THERMOGUARD
21	201098	Not Available	TIMER
22	201001	Not Available	TIMER MOTOR 240-50
23	<a href="#">201619</a>		Timer Motor
24	201012	Not Available	ESCAPEMENT FOR TIMER

